

1 Reset Configuration to Defaults



0B

2 Auto-Sensor Mode Option

On



001901

Off



001900

3 Laser on Trigger

9s



01111119

4 Keyboard Language

Reset to USA



0005025